



ODR (ON DEMAND REPORTS)

Double-click the Fast Track Shortcuts Icon on the desktop to open the shortcuts folder.



Select an ODR (On Demand Report).
Double-click the icon for the selected report.
Reports available: ODR Daily, ODR Dayparts 1-8.


NOTE: ODRs are only available for the current day.
A report cannot be created for a Daypart that has not occurred (e.g. A report cannot be created for Daypart 3 if the timer is still in Daypart 2).
Reports cannot be created for Dayparts that do not exist (e.g. A report cannot be created for Daypart 7 if the timer is only programmed through Daypart 6).



After double-clicking an ODR icon, a dialog box will open, the software will connect to the timer and download the current speed-of-service data. This may take a few moments.

NOTE: The more frequent reports are generated, the more often the speed-of-service data file is updated and the less time it will take to complete a download.

ODR (ON DEMAND REPORTS)



```

04:57PM 11/13/08
Fast Track Demo
Start Daily Stop
06:00AM <> 12:00AM
11/13/08
A Side #Cars Avq
MENU 524 22
GREET 525 3
WIN1 524 25
WIN2 525 39
LINE 523 127

Avg Cars/Lane = 2.0
Pull Outs = 0

Event: MENU
Target #Cars %
A <= 30 524 100

Event: GREET
Target #Cars %
A <= 4 350 67
B <= 7 175 33

Event: WIN1
Target #Cars %
A <= 30 349 67
B <= 45 175 33

Event: WIN2
Target #Cars %
D <= 45 525 100

Event: LINE
Target #Cars %
A <=150 349 67
B <=180 174 33
    
```

Once the download is complete, the selected report will display in the Print Preview window.
NOTE: If the Print Preview Window displays a blank report, no data was downloaded or available for that Day or Daypart. Make sure that a current Daypart was selected.

Sample ODR DAILY report. Reports are easily viewed and printed from the Print Preview Window.



Buttons at the top of the Print Preview window provide several options:

- Print** Sends the report to a user specified printer
- Zoom In** Increases magnification of the document
- Zoom Out** Decreases magnification of the document
- Close** Closes the Print Preview window

REMOTE MONITOR/REMOTE CONTROL



REMOTE MONITOR



REMOTE CONTROL



Double-click the Remote icon to connect to the timer, open Remote Monitor and view the timer activity screen in real time.



Double-click the Remote Control icon to connect to the timer and open Remote Control. View the timer activity screen in real-time and/or use the mouse pointer to click timer keys to access timer functions





Fast Track[®] 2+2 ODR (ON DEMAND REPORTS) QUICK REFERENCE GUIDE

ODR REPORT GENERATOR


Double-click the Fast Track Shortcuts Icon on the desktop to open the shortcuts folder.



Double-click the Reports icon to open the Report Generator.



From the Report Generator: Check the Download box. Click the DAYPART - DAILY button repeatedly to select Daypart (1-8) or for Daily. Click Create ODR.




After clicking Create ODR, the software will connect to the timer and download current speed-of-service data. This may take a few moments. Current and Archive reports can now be generated.



Once the download is complete, the ODR report will display in the Print Preview window. NOTE: If the Print Preview Window shows a blank report, no data was downloaded or available for that Day or Daypart. Make sure that a current Daypart was selected.


ODR REPORT GENERATOR




Buttons at the top of the Print Preview window provide several options:

- Print** Sends the report to a user specified printer.
- Zoom In** Increases magnification of the document.
- Zoom Out** Decreases magnification of the document.
- Close** Closes the Print Preview window.


MANUAL/ARCHIVE REPORT GENERATOR



From the Report GUI, use the Month/Year drop down arrows to select the desired month and year. Use the calendar to select the date for the data that is to be generated.



Select the type of report to be generated using the radio buttons under "Type". Report types available: Events, Archive, Target, Period and Car (Car by Car).



Use the radio buttons to select the desired time-frame for the report. Day, Week, Month, YTD (Year to Date), All (all data stored in the timer's memory) or RLG (Rolling - specified # of days). NOTE: YTD, All and RLG are not available for all report types.

